UV risk control for outdoor work.

Use this worksheet to assess if there is a risk of hazardous levels of exposure to ultraviolet (UV) radiation from the sun associated with performing a role in your organisation.

Work location:				Descrip	tion of tas	k(s) perfor	med:		
Assessed by:									
Health & Safety Representati	ve:								
Date:									
1. UV risk assessment									
To assess UV risk, tick the most r please assess the risk based on t				ow. Each	category a	dds to the	accumulated le	evel of risk;	
VERY HIGH		HIGH	MODERATE			Έ	Low		
Time of day spent in the sun (i	ncluding in	ı vehicles v	without t	inting)					
all day 10am-3p	m 3-	5pm	8-10	0am after 5pm		before 8am	at night		
Altitude of worksite									
more than 1500m	1000-1500m			500-1000m			less than 500m		
Season when work takes place	e								
all year	summer		autumn/spring			winter			
Shade during work									
no shade	partial shade		total shade			indoor wo	ork		
Shade at rest breaks									
no shade/partial shade total shade			indo			oor break area			
Latitude (proximity to equato	r)								
QLD, NT, northern WA VIC, SA, southe			n WA, NSW, ACT TAS						

2. Assessment of hazardous factors

The presence of reflective surfaces increases the risks posed by UV radiation exposure.

Photosensitivity:
Certain substances increase sensitivity to UV radiation, meaning sunburn occurs more quickly. Substances that cause photosensitivity include industrial chemicals, drugs, plants, fragrances and some medications.
check the MSDS to identify substances that cause photosensitivity
advise workers to consult their GP if taking medication that may cause photosensitivity
Presence of reflecting substances:
snow
sand
house paint (white)
concrete
☐ glass
roofing iron
water water
other
3. Assessment of protective factors
Personal protective equipment (PPE) in use:
portable shade structure
onstruction helmet with brim attachment
broad-brimmed, bucket or legionnaire-style hat
shirt with longer sleeves and a collar made from UFP50+ material
trousers (or knee length shorts) made from UFP50+ material
sunscreen with SPF30 (or higher)
wrap-ground sunglasses (AS/NZS 1067/FPE of 9 or 10) or safety glasses (AS/NZS 13371·2010)

4. Identification of risk control measures

Use of engineering controls

OPTIONS/ACTIONS	1	X	TIMEFRAME (short/medium/long)
Use shade (natural, portable, or permanent structures)			
Modify reflective surfaces or move work away from these surfaces			
Provide window tinting for work vehicles			
• Other			

Use of administrative controls

OPTIONS/ACTIONS	1	X	TIMEFRAME (short/medium/long)
Reschedule outdoor work:			
• Outdoor tasks are done early in the morning or later in the afternoon when levels of UV radiation are lower			
• Shaded work is done in the middle of the day.			
Move jobs indoors or into shaded areas.			
Rotate staff and work, so that the same person is not always outside.			
• Supervisors refer to the SunSmart app to check current UV levels for their location. Download the free SunSmart app or check the widget at sunsmart.com.au/widget			

Use of personal protective equipment and clothing

OPTIONS/ACTIONS	1	X	TIMEFRAME (short/medium/long)
Clothing:			
• Provide a uniform or require work wear that has long sleeves, long pants and a collar.			
 Use sun-protective fabrics—those with a tight weave or rated with an ultraviolet protection factor (UPF) of 50+ is recommended (AS/NZS 4399). 			
Hats:			
 Provide or require the use of a UV-protective hat in legionnaire, broad-brimmed or bucket style, or attachable brims and neck flaps for hard hats or helmets. 			
Sunglasses:			
• Provide or encourage the use of wrap-around sunglasses (AS/NZS 1067 or with an EPF of 9 or 10) or safety glasses (AS/NZS 1337.1).			
Sunscreen:			
 Purchase broad-spectrum, water-resistant sunscreen that is SPF30 (or higher) and make it easily accessible. 			
 Encourage staff to apply sunscreen 20 minutes before going outdoors, and to reapply it every two hours, and/or if they get wet or perspire. 			



